


**Numbering order scheme for End-Cap feed-throughs (Ver. 4.0 2003/Oct/30)**



FT-E01L-S	:	BNC - lemo
FT-E12L-S	:	(typical 56ch/each)
FT-E13L-S	:	BNC - lemo (short length)
FT-E14L-S	:	(for KTeV CsI)
FT-E01L-HS	:	SHV - SHV
FT-E04L-HS	:	(36ch/each)
FT-E03L-HL	:	SHV - lemo type HV
FT-E12L-HL	:	(typical 56ch/each)